

## Parofluor ULTRA™ Series Perfluorinated Elastomer Materials

Parofluor ULTRA series materials incorporate the ultimate elastomer polymer technology to offer maximum resistance to a broad range of process chemistries. These materials are formulated to retain their physical properties at extremely high temperatures and reduce system contamination (see figures 1-3).

For additional information please visit [www.parofluor.com](http://www.parofluor.com)

Figure 1




Figure 2





Figure 3



### DESIGN ASSISTANCE

Parker Seal offers a dedicated applications engineering staff, finite element analysis (FEA) assisted design, and many other services to assist in the specification of the right Parofluor seal material.

For more information, call 1-859-269-2351.

**Total System Solutions:** Parker's Seal Group offers a complete line of O-rings, custom molded shapes, composite (rubber/metal and rubber/plastic) seals, PTFE and thermoplastic seals, bumpers, dust covers, diaphragms, isolators, washers and thermoset injection molded boots and bellows for a wide variety of applications. Parker's "total systems sealing" approach can help customers reduce costs and improve efficiency.

*This document contains information that is confidential and proprietary to Parker Hannifin Corp., O-Ring Division. It is furnished with the understanding that the document and the information it contains will not be copied or disclosed to others or used for any purpose other than conducting business with Parker, and will be returned and all further use discontinued upon request by Parker.*

*Unless otherwise noted, all test values are obtained from a limited number of samples, and should not be used for establishing specific limitations.*

## Perfluorinated Elastomer Media Compatibility Tables for Semiconductor Service

Parofluor™ is a unique, advanced perfluorinated elastomer (FFKM) family developed and produced exclusively by Parker Seals. Perfluorinated elastomers provide performance beyond all other available elastomer families.

Parofluor ULTRA™ series materials are high performance perfluorinated elastomers designed specifically for use in harsh operating environments where superior thermal stability, chemical resistance and ultra high-purity are required.

### Parofluor ULTRA™ Materials Offering



Parker Compound	Color	Nominal Hardness (Shore A)	Temperature Range	Features
FF200-75	Black	75	-15°C to 320°C 5°F to 608°F	High temperature, low compression set, chemical resistance
FF202-90	Black	90	-15°C to 320°C 5°F to 608°F	Extrusion resistant, high temperature, low compression set, chemical resistance
FF350-75	White	75	-15°C to 316°C 5°F to 600°F	High purity, high temperature
FF352-75	White	75	-15°C to 316°C 5°F to 600°F	General purpose, high temperature
FF354-65	White	65	-15°C to 316°C 5°F to 600°F	Low closure force material, high temperature
FF500-75	Black	75	-15°C to 260°C 5°F to 525°F	Best chemical resistance

### Parofluor™ Materials Offering

Parker Compound	Color	Nominal Hardness (Shore A)	Temperature Range
V1266-65	White	65	-15°C to 300°C 5°F to 572°F
V8545-75	Black	75	-15°C to 300°C 5°F to 572°F
V8562-75	White	75	-15°C to 300°C 5°F to 572°F
V8588-90	Black	90	-15°C to 280°C 5°F to 536°F
V8581-90	White	90	-15°C to 300°C 5°F to 572°F



### COMPOUND COMPATIBILITY RATING

- 1 Satisfactory
- 2 Fair (normally okay for static seal)
- 3 Doubtful (sometimes okay for static seal)
- 4 Unsatisfactory
- X Insufficient data

Compatibility rating charts, pages 2-4



## Semiconductor Media Compatibility

CHEMICAL	FORMULA	Parofluor ULTRA	Parofluor	FKM
Acetic acid 30%	CH <sub>3</sub> COOH	1	1	X
Acetic acid, Glacial	CH <sub>3</sub> COOH	1	1	2
Acetone	CH <sub>3</sub> COCH <sub>3</sub>	1	1	4
Ammonia	NH <sub>3</sub>	1	1	4
Ammonium fluoride	NH <sub>4</sub> F	1	1	1
Ammonium hydroxide	NH <sub>4</sub> OH	1	1	4
Ammonium persulfate	(NH <sub>4</sub> ) <sub>2</sub> S <sub>2</sub> O <sub>8</sub>	1	1	4
Aqua Regia	HNO <sub>3</sub> :HCl(1:3)	1	1	2
Argon	Ar	1	1	1
Arsenic trioxide	As <sub>2</sub> O <sub>3</sub>	1	1	4
Arsine	AsH <sub>3</sub>	1	1	X
Boron tribromide	BBr <sub>3</sub>	1	1	X
Boron trichloride	BCl <sub>3</sub>	1	1	X
Bromine	Br <sub>2</sub>	1	1	1
Bromide trifluoride	BrF <sub>3</sub>	1	1	4
Bromotrifluoroethylene (BFE)	BrFC:CF <sub>2</sub>	1	1	X
Buffered Oxide Etchants (BOE)	NH <sub>4</sub> :HF	1	1	X
Butyl (n-) acetate	CH <sub>3</sub> COO(CH <sub>2</sub> ) <sub>4</sub>	1	1	4
Carbon dioxide	CO <sub>2</sub>	1	1	1
Carbon tetrachloride	CCl <sub>4</sub>	1	1	1
Chlorine	Cl <sub>2</sub>	1	1	X
Chlorine trifluoride	ClF <sub>3</sub>	1	1	4
Chloroform	CHCl <sub>3</sub>	1	1	1
Chromic acid (50%)	H <sub>2</sub> CrO <sub>4</sub>	1	1	1
Cyclohexanone	C <sub>6</sub> H <sub>10</sub> O	1	1	4
Deionized water (UPDI)	H <sub>2</sub> O	1	1	2
Diborane	B <sub>2</sub> H <sub>6</sub>	1	1	X
Diethylene glycol monomethyl ether (DGMME)	CH <sub>3</sub> O(CH <sub>2</sub> ) <sub>2</sub> O(CH <sub>2</sub> ) <sub>2</sub> OH	1	1	4
Dimethyl acetamide (DMAC)	CH <sub>3</sub> CON(CH <sub>3</sub> ) <sub>2</sub>	1	1	3
Dimethyl ether	CH <sub>3</sub> OCH <sub>3</sub>	1	1	2
Dimethyl sulfoxide (DMSO)	(CH <sub>3</sub> ) <sub>2</sub> SO	1	1	3
Dimethylamine (DMA)	(CH <sub>3</sub> ) <sub>2</sub> NH	1	1	4
Ethyl acetate	CH <sub>3</sub> COOC <sub>2</sub> H <sub>5</sub>	1	1	4
Ethyl lactate (EL)	CH <sub>3</sub> CHOHCOOC <sub>2</sub> H <sub>5</sub>	1	1	3
Ethylene	H <sub>2</sub> C:CH <sub>2</sub>	1	1	2
Ethylene glycol	(CH <sub>2</sub> OH) <sub>2</sub>	1	1	1
Ethylene glycol monoethyl ether acetate(EGMEEA)	CH <sub>3</sub> COO(CH <sub>2</sub> ) <sub>2</sub> OC <sub>2</sub> H <sub>5</sub>	1	1	4
F-11 (CFC) (Trichlorofluoromethane)	CFCl <sub>3</sub>	1	1	2
F-12 (CFC) (Dichlorodifluoromethane)	CF <sub>2</sub> Cl <sub>2</sub>	1	1	3
F-13 (CFC) (Chlorotrifluoromethane)	CF <sub>3</sub> Cl	1	1	1

1 Satisfactory    2 Fair (normally okay for static seal)    3 Doubtful (sometimes okay for static seal)    4 Unsatisfactory    X Insufficient data



## Semiconductor Media Compatibility

CHEMICAL	FORMULA	Parofluor ULTRA	Parofluor	FKM
F-13B1 (FC)(Bromotrifluoromethane)	CBrF <sub>3</sub>	1	1	1
F-14 (FC) (Tetrafluoromethane)	CF <sub>4</sub>	1	1	1
F-22 (HCFC) (Chlorodifluoromethane)	CHClF <sub>2</sub>	1	1	4
F-23 (HFC) (Fluoroform)	CHF <sub>3</sub>	1	1	X
F-113 (CFC) (Trichlorotrifluoroethane)	CCl <sub>2</sub> FCClF <sub>2</sub>	1	1	2
F-115 (CFC) (Chloropentafluoroethane)	CClF <sub>2</sub> CF <sub>3</sub>	1	1	2
F-116 (FC) (Hexafluoroethane)	C <sub>2</sub> F <sub>6</sub>	1	1	2
F-123 (HCFC) (Dichlorotrifluoroethane)	CF <sub>3</sub> CHCl <sub>2</sub>	1	1	X
F-124 (CFC) (Chlorotetrafluoroethane)	C <sub>2</sub> CF <sub>4</sub> Cl	1	1	X
F-125 (HFC) (Pentafluoroethane)	C <sub>2</sub> HF <sub>5</sub>	1	1	X
F-134a (HFC) (Tetrafluoroethane)	CF <sub>3</sub> CH <sub>2</sub> F	1	1	X
F-141b (HCFC) (Dichlorofluoroethane)	CFCl <sub>2</sub> CH <sub>3</sub>	1	1	X
F-142b (HCFC) (Difluoroethane)	CF <sub>2</sub> ClCH <sub>3</sub>	1	1	2
F-152a (HCFC) (Difluoroethane)	CH <sub>3</sub> CHF <sub>2</sub>	1	1	X
Fluorine (gas)	F	1	1	4
Germane	GeH <sub>4</sub>	1	1	X
Helium	He	1	1	1
Hexamethyldisilazane (HMDS)	(CH <sub>3</sub> ) <sub>3</sub> SiNHSi(CH <sub>3</sub> ) <sub>3</sub>	1	1	X
Hydrochloric acid (37%)	HCl	1	1	1
Hydrofluoric acid (40%)	HF	1	1	
Hydrogen	H <sub>2</sub>	1	1	1
Hydrogen bromide	HBr	1	1	X
Hydrogen chloride	HCl	1	1	X
Hydrogen fluoride	HF	1	1	X
Hydrogen peroxide	H <sub>2</sub> O <sub>2</sub>	1	1	1
Hydrogen selenide	H <sub>2</sub> Se	1	1	X
Hydrogen sulfide	H <sub>2</sub> S	1	1	4
Iodine pentafluoride	IF <sub>5</sub>	1	1	4
Isobutane	(CH <sub>3</sub> ) <sub>2</sub> CHCH <sub>3</sub>	1	1	1
Isopropyl alcohol (IPA)	(CH <sub>3</sub> ) <sub>2</sub> CHOH	1	1	1
MEA (Ethanolamine)	HO(CH <sub>2</sub> ) <sub>2</sub> NH <sub>2</sub>	1	1	4
MEK (Methyl ethyl ketone)	CH <sub>3</sub> COCH <sub>2</sub> CH <sub>3</sub>	1	1	4
Methane	CH <sub>4</sub>	1	1	1
Methanethiol	CH <sub>3</sub> SH	1	1	4
Methyl alcohol	CH <sub>3</sub> OH	1	1	4
Methyl bromide	CH <sub>3</sub> Br	1	1	1
Methyl chloride	CH <sub>3</sub> Cl	1	1	1
Methylamine	CH <sub>3</sub> NH <sub>2</sub>	1	1	3
Methylene chloride	CH <sub>2</sub> Cl <sub>2</sub>	1	1	2
MIBK (Methyl isobutyl ketone)	(CH <sub>3</sub> ) <sub>2</sub> CHCH <sub>2</sub> COCH <sub>3</sub>	1	1	4

1 Satisfactory    2 Fair (normally okay for static seal)    3 Doubtful (sometimes okay for static seal)    4 Unsatisfactory    X Insufficient data



## Semiconductor Media Compatibility

CHEMICAL	FORMULA	Parofluor Ultra	Parofluor	FKM
Nitric acid (0-50%)	HNO <sub>3</sub>	1	1	1
Nitrogen	N <sub>2</sub>	1	1	1
Nitrogen trifluoride	NF <sub>3</sub>	1	1	X
Nitrous oxide	N <sub>2</sub> O	1	1	1
NMP (Methyl(n-)pyrrolidone(2-))	CH <sub>3</sub> NCH <sub>2</sub> CH <sub>2</sub> CH <sub>2</sub> CO	1	1	X
Octafluoropropane	C <sub>3</sub> F <sub>8</sub>	1	1	2
Oxygen	O <sub>2</sub>	1	1	1
Ozonated deionized water	O <sub>3</sub> :H <sub>2</sub> O	1	1	3
Ozone	O <sub>3</sub>	1	1	1
Phosgene	COCl <sub>2</sub>	1	1	X
Phosphine	PH <sub>3</sub>	1	1	X
Phosphoric acid (20%)	H <sub>3</sub> PO <sub>4</sub>	1	1	X
Phosphorous oxychloride	POCl <sub>3</sub>	1	1	X
Piranha fluid	H <sub>2</sub> SO <sub>4</sub> :H <sub>2</sub> O <sub>2</sub>	1	1	X
Potassium hydroxide	KOH	1	1	4
Silane	SiH <sub>4</sub>	1	1	X
Silicon tetrachloride	SiCl <sub>4</sub>	1	1	X
Silicon tetrafluoride	SiF <sub>4</sub>	1	1	X
Sodium hydroxide	NaOH	1	1	2
Standard Clean 1 (SC-1)	NaOH:H <sub>2</sub> O <sub>2</sub>	1	1	
Standard Clean 2 (SC-2)	HCl:H <sub>2</sub> O	1	1	
Stoddard solvent	-	1	1	1
Sulfur hexafluoride	SF <sub>6</sub>	1	1	3
Sulfur tetrafluoride	SF <sub>4</sub>	1	1	X
Sulfuric acid (conc.)	H <sub>2</sub> SO <sub>4</sub>	1	1	1
TEOS (Tetraethylorthosilicate)	(C <sub>2</sub> H <sub>5</sub> ) <sub>4</sub> SiO <sub>4</sub>	1	1	X
Tetrahydrofuran (THF)	CH <sub>2</sub> CH <sub>2</sub> CH <sub>2</sub> CH <sub>2</sub> O	1	1	4
Tetramethyl ammonium hydroxide (TMAH)	(CH <sub>3</sub> ) <sub>4</sub> NOH	1	1	3
Toluene	C <sub>6</sub> H <sub>5</sub> CH <sub>3</sub>	1	1	1
Trichloroacetic acid (TCA)	CCl <sub>3</sub> COOH	1	1	3
Trichloroethylene (TCE)	CHCl:CCl <sub>2</sub>	1	1	1
Trichlorosilane	SiHCl <sub>3</sub>	1	1	1
Trimethylamine (TMA)	(CH <sub>3</sub> ) <sub>3</sub> N	1	1	3
Trimethyl borate (TMB)	(CH <sub>3</sub> O) <sub>3</sub> B	1	1	1
Trimethyl phosphite (TMP)	(CH <sub>3</sub> O) <sub>3</sub> P	1	1	2
Vinyl chloride (VC)	CH <sub>2</sub> :CHCl	1	1	1
Vinyl fluoride	CH <sub>2</sub> :CHF	1	1	1
Xenon	Xe	1	1	1
Xylene	C <sub>6</sub> H <sub>4</sub> (CH <sub>3</sub> ) <sub>2</sub>	1	1	1

1 Satisfactory    2 Fair (normally okay for static seal)    3 Doubtful (sometimes okay for static seal)    4 Unsatisfactory    X Insufficient data



## General Properties of Parofluor ULTRA™ Materials

### Parker Compound: FF200-75

Black, ultra high temperature, 75 Shore A Parofluor ULTRA™, Perfluorinated Elastomer

-15°C to 320°C (5°F to 608°F)

Property	Typical Results
Original Properties, ASTM D1414	
Shore A Hardness	79
Tensile Strength, MPa	12.0
Elongation, %	124
Modulus at 100% Elongation, MPa	7.8
Compression Set, 70 hours at 200°C, ASTM D395 Method B, 2-214 Size O-Rings	
% Permanent Set	12
Compression Set, 70 hours at 316°C, ASTM D395 Method B, 2-214 Size O-Rings	
% Permanent Set	45
Low Temperature Retraction, ASTM D1329	
TR-10 in degrees C	-2
Volume Change, 70 hours at room temperature, ASTM D471	
Acetone, % Volume Change	0.4
Methyl Ethyl Ketone, % Volume Change	0.2
Methanol, % Volume Change	0.2
Benzene, % Volume Change	0.3
Toluene, % Volume Change	0.3
Dichloromethane, % Volume Change	0.6
Chloroform, % Volume Change	0.6
Ethyl Acetate, % Volume Change	0.4
MTBE, % Volume Change	0.2
Glacial Acetic Acid, % Volume Change	0.4
Conc. Phosphoric Acid, % Volume Change	0.0
50/50 by Volume, MEK/Methanol	% Volume Change
% Volume Change	0.7
Tetrahydrofuran (THF), % Volume Change	0.4
Styrene Monomer, % Volume Change	0.0
Methyl Methacrylate Monomer, % Vol. Change	0.5

### Parker Compound: FF202-90

Black, ultra high temperature, 90 Shore A Parofluor ULTRA™, Perfluorinated Elastomer

-15°C to 320°C (5°F to 608°F)

Property	Typical Results
Original Properties, ASTM D1414	
Shore A Hardness	91
Tensile Strength, MPa	20.5
Elongation, %	110
Modulus at 100% Elongation, MPa	15.1
Compression Set, 70 hours at 200°C, ASTM D395 Method B, 2-214 Size O-Rings	
% Permanent Set	25
Low Temperature Retraction, ASTM D1329	
TR-10 in degrees C	-2
Volume Change, 70 hours at room temperature, ASTM D471	
Acetone, % Volume Change	0.5
Methyl Ethyl Ketone, % Volume Change	0.3
Methanol, % Volume Change	0.4
Benzene, % Volume Change	0.4
Toluene, % Volume Change	0.4
Dichloromethane, % Volume Change	0.7
Chloroform, % Volume Change	0.8
Ethyl Acetate, % Volume Change	0.4
MTBE, % Volume Change	0.2
Glacial Acetic Acid, % Volume Change	0.4
Conc. Phosphoric Acid, % Volume Change	0.2
50/50 by Volume, MEK/Methanol	% Volume Change
% Volume Change	0.9
Tetrahydrofuran (THF), % Volume Change	0.5
Styrene Monomer, % Volume Change	0.1
Methyl Methacrylate Monomer, % Vol. Change	0.6



## General Properties of Parofluor ULTRA™ Materials

### Parker Compound: FF350-75

White, high purity, high temperature, 75 Shore A Parofluor ULTRA™, Perfluorinated Elastomer -15°C to 316°C (5°F to 600°F)

Property	Typical Results
Original Properties, ASTM D1414	
Shore A Hardness	74
Tensile Strength, MPa	16.3
Elongation, %	125
Modulus at 100% Elongation, MPa	9.4
Compression Set, 70 hours at 200°C, ASTM D395 Method B, 2-214 Size O-Rings	
% Permanent Set	13
Compression Set, 70 hours at 260°C, ASTM D395 Method B, 2-214 Size O-Rings	
% Permanent Set	26
Low Temperature Retraction, ASTM D1329	
TR-10 in degrees C	-1
Volume Change, 70 hours at room temperature, ASTM D471	
Acetone, % Volume Change	0.3
Methyl Ethyl Ketone, % Volume Change	0.2
Methanol, % Volume Change	0.2
Benzene, % Volume Change	0.3
Toluene, % Volume Change	0.3
Dichloromethane, % Volume Change	0.5
Chloroform, % Volume Change	0.5
Ethyl Acetate, % Volume Change	0.4
MTBE, % Volume Change	0.3
Glacial Acetic Acid, % Volume Change	0.1
Conc. Phosphoric Acid, % Volume Change	0.1
50/50 by Volume, MEK/Methanol	
% Volume Change	0.6
Tetrahydrofuran (THF), % Volume Change	0.4
Styrene Monomer, % Volume Change	0.2
Methyl Methacrylate Monomer, % Vol. Change	0.3

### Parker Compound: FF352-75

White, clean, high temperature, 75 Shore A Parofluor ULTRA™, Perfluorinated Elastomer -15°C to 316°C (5°F to 600°F)

Property	Typical Results
Original Properties, ASTM D1414	
Shore A Hardness	76.0
Tensile Strength, MPa	16.9
Elongation, %	142.0
Modulus at 100% Elongation, MPa	9.2
Compression Set, 70 hours at 200°C, ASTM D395 Method B, 2-214 Size O-Rings	
% Permanent Set	16
Compression Set, 70 hours at 260°C, ASTM D395 Method B, 2-214 Size O-Rings	
% Permanent Set	28
Low Temperature Retraction, ASTM D1329	
TR-10 in degrees C	-1
Volume Change, 70 hours at room temperature, ASTM D471	
Acetone, % Volume Change	0.2
Methyl Ethyl Ketone, % Volume Change	0.1
Methanol, % Volume Change	0.1
Benzene, % Volume Change	0.2
Toluene, % Volume Change	0.2
Dichloromethane, % Volume Change	0.3
Chloroform, % Volume Change	0.4
Ethyl Acetate, % Volume Change	0.3
MTBE, % Volume Change	0.2
Glacial Acetic Acid, % Volume Change	0.0
Conc. Phosphoric Acid, % Volume Change	0.1
50/50 by Volume, MEK/Methanol	
% Volume Change	0.5
Tetrahydrofuran (THF), % Volume Change	0.4
Styrene Monomer, % Volume Change	0.2
Methyl Methacrylate Monomer, % Vol. Change	0.3



## General Properties of Parofluor ULTRA™ Materials

### Parker Compound: FF354-65

Low closure force, white, high temp., 65 Shore A Parofluor ULTRA™, Perfluorinated Elastomer -15°C to 316°C (5°F to 600°F)

Property	Typical Results
Original Properties, ASTM D1414	
Shore A Hardness	65
Tensile Strength, MPa	8.0
Elongation, %	277
Modulus at 100% Elongation, MPa	1.8
Compression Set, 70 hours at 200°C, ASTM D395 Method B, 2-214 Size O-Rings	
% Permanent Set	28
Compression Set, 70 hours at 260°C, ASTM D395 Method B, 2-214 Size O-Rings	
% Permanent Set	41
Low Temperature Retraction, ASTM D1329	
TR-10 in degrees C	-1
Volume Change, 70 hours at room temperature, ASTM D471	
Acetone, % Volume Change	0.2
Methyl Ethyl Ketone, % Volume Change	0.2
Methanol, % Volume Change	0.1
Benzene, % Volume Change	0.2
Toluene, % Volume Change	0.1
Dichloromethane, % Volume Change	0.3
Chloroform, % Volume Change	0.5
Ethyl Acetate, % Volume Change	0.3
MTBE, % Volume Change	0.1
Glacial Acetic Acid, % Volume Change	0.1
Conc. Phosphoric Acid, % Volume Change	0.1
50/50 by Volume, MEK/Methanol	
% Volume Change	0.7
Tetrahydrofuran (THF), % Volume Change	0.4
Styrene Monomer, % Volume Change	0.3
Methyl Methacrylate Monomer, % Vol. Change	0.2

### Parker Compound: FF500-75

Black, best chemical resistance, 75 Shore A Parofluor ULTRA™, Perfluorinated Elastomer -15°C to 276°C (5°F to 525°F)

Property	Typical Results
Original Properties, ASTM D1414	
Shore A Hardness	80
Tensile Strength, MPa	14.1
Elongation, %	135
Modulus at 100% Elongation, MPa	8.7
Compression Set, 70 hours at 230°C, ASTM D395 Method B, 2-214 Size O-Rings	
% Permanent Set	23
Compression Set, 70 hours at 200°C, ASTM D395 Method B, 2-214 Size O-Rings	
% Permanent Set	19
Low Temperature Retraction, ASTM D1329	
TR-10 in degrees C	-1
Volume Change, 70 hours at room temperature, ASTM D471	
Acetone, % Volume Change	0.1
Methyl Ethyl Ketone, % Volume Change	0.2
Methanol, % Volume Change	0.2
Benzene, % Volume Change	0.3
Toluene, % Volume Change	0.3
Dichloromethane, % Volume Change	0.9
Chloroform, % Volume Change	0.6
Ethyl Acetate, % Volume Change	0.4
MTBE, % Volume Change	0.5
Glacial Acetic Acid, % Volume Change	0.3
Conc. Phosphoric Acid, % Volume Change	0.1
50/50 by Volume, MEK/Methanol	
% Volume Change	0.7
Tetrahydrofuran (THF), % Volume Change	0.6
Styrene Monomer, % Volume Change	0.3
Methyl Methacrylate Monomer, % Vol. Change	0.3